

# Measuring Instructions: Vertical Blinds For Sliding Patio Doors

## Sliding Patio Doors

Vertical blinds are the most practical window covering option for sliding patio doors where they are fitted **inside recess** of the door.

## Tilt & Slide Patio Doors

Some versions of patio doors tilt inwards before sliding back leaving little room for the blind to be fitted, in the case the blind can be fitted on the **outside recess**.

## Useful Information & Tips

Use a metal tape measure to ensure accurate measurements.



### Inside Recess

#### **Width**

Measure the width of the **inside recess** at 3 points, making sure the top of the recess and the skirting recess are measured. Use the smallest measurement.

#### **Drop**

Measure the drop of the door recess at 3 points and use the smallest one.

Order as **Recess Size**.

### Outside Recess

#### **Width**

Measure the width of the **inside recess** wall to wall then add on 30cm to allow for an overhang around the recess of 15cm either side. Check there are no obstructions.

#### **Drop**

Measure the recess drop to the floor, then add on 10cm. This will allow for bracket fixings and the head-rail.

Order as **Exact Size**.