

Measuring Instructions: Roller Blinds for Bifolding Doors

Our roller blinds for bifolding doors are designed to be fitted **inside the recess** of the door reveal. The blinds are not intended to be screwed into the doors themselves.

Roller blinds can only be installed on bifolding door recesses where the doors concertina outwards.

Useful Information & Tips

Use a metal tape measure as cloth ones can be inaccurate.

The overall width of roller blinds including brackets is approximately 35mm wider than the fabric.

Make sure the recess is deep enough taking door handles into account allowing 53mm for the depth of the bracket.

Blinds are produced within an operating tolerance of +/-3mm.

Door Configurations

Bifolding doors come in various configurations, most commonly **4/5/6 doors**. However to avoid the control chains hanging down we only recommend corded roller blinds on the 4 door configuration where you would want 2 blinds. Cordless or electric roller blinds can be used on larger configurations.

Decide if you want:

- a) Blinds of **equal size** to each other to cover the recess space
- or**
- b) Blinds of **different sizes** to each other to cover the recess space.

a) Equal sized blinds

Width

Measure the overall recess space from wall to wall then divide by the number of blinds you require, then **subtract 5mm** from each blind size.

e.g. Overall recess 3500mm with 4 doors. 2 blinds required = $3500/2 = 1750\text{mm} - 5\text{mm} = 1745\text{mm}$ each blind

Drop

Measure from the top inside recess where the brackets are fitted to the floor.

Order each blind as **bracket to bracket size**.

b) Different sized blinds

Width

Use a pencil to place a small mark on the recess where each bracket will be fitted, then measure the size between each mark.

Drop

Measure from the top inside recess where the brackets are fitted to the floor, do not make any deductions.

Order each blind as **bracket to bracket size**.

Bracket Dimensions

