

# Fitting Instructions: Rigid PVC Replacement Vertical Blind Slats

Before hanging the rigid PVC slats make sure that the headrail hooks are facing the left or right hand side of the headrail, not the front or back of the headrail as shown in the illustrations below.

