

How to fit Venetian blinds

1 During the ordering process, you will have selected either 'inside recess' or 'outside recess' measurement's.

outside recess - face fix brackets

inside recess - top fix or face fix brackets

2 Brackets

There are 5 different brackets available for venetian blinds, 2 top fix and three universal brackets (top and face fix).

Follow the instructions for the brackets that you received with your blinds.

swivel bracket

top fix

top fix & face fix

top fix & face fix

cage bracket

top fix & face fix

3 Swivel Bracket

These brackets can fit anywhere along the blind.

Slide the bracket in to the head rail and then swivel the bracket arm clockwise to lock the blind in position

turn clockwise to lock bracket in position

4 Push-Fit Bracket

This bracket can fit anywhere along the blind. I would recommend fitting a bracket 5cm in from each end of the blind.

After the brackets have been installed, push the front edge of the blind against the front of the brackets (note - the brackets are spring loaded)

The brackets should compress and then allow the back of the blind to hook into the position shown

Follow the same procedure as above if the blind needs removing. Push the blind forwards against the spring and lower the back of the blind to release it

5 Cage Bracket

These brackets come in a pair, one for each end of the blind.

The brackets can be fitted using any of the holes.

Tools suggested

- screwdriver
- drill (5mm)
- pencil
- tape measure
- spirit level
- screws
- wall plugs

In the box

x2

x2

or

or

x1

Your blind should come with a child safety device which must be screwed into the wall during the installation of the blind to prevent the cords/chains creating a loop. Failure to fit this device could result in strangulation.

[Click here to shop venetian blinds](#)